




Profiles - Objectives


- What is an InRoads Profile?
- Creating new Profiles
- Sources of Profiling paths
- Display of surfaces & offsets on profiles
- Available Profiling Controls
- Displaying Surface Features on Profiles
- Updating the Profile once it's been cut
- Batch loading & saving InRoads data

InRoads Profile Defined




- InRoads defines its profile as
 - A graph showing elevation extracted from one or more surfaces along a defined path, such as along an alignment. [InRoads On-line Help file]

An InRoads Profile




- As far as an InRoads Profile is concerned -
 - ♣ An InRoads profile refers to an Elev./Sta. 'graph'
 - ♣ An InRoads profile displays DTM data
 - ♣ The Vertical Design is not a Profile
 - ♣ The Vertical Design is an 'overlay' on a profile

An InRoads Profile




- This is an InRoads Profile
- Does not follow the Pen / Pencil Lock rules
- If anything on this window requires changing – delete the profile / change the command settings / display a new profile window

Profiling



- New Profiles are *created* under **Evaluation > Profile > Create Profile...**
- An InRoads Profile is a composite of the DTM data and the Geometry data


Profiling – Set-up



- The profile components are defined on the various tabs
- Set up the **Controls, Axes, Grid, ...**etc. to match required standards
- Different profile configurations are named and saved in the *civil.xin* file using the usual *Preferences* button


Different Display Configuration

- Variations in color, fonts, levels, grids, weights, ...etc., may be set to conform to departmental display standards
- Store these different setups as Preference Sets to be reused later as needed





Profiling – General Leaf

- Define the:
 - *Set Name*
 - *Direction*
 - *Exaggeration*
 - *Surfaces to Display*
- Remember that the DTM Symbology is determined by the *Surface Property* of the particular surface




Vertical Exaggeration

- Vertical exaggerations are for display and plotting only, the data is not modified.




Profile – Source Leaf

- There are 4 Profile Sources:
 - Alignment
 - Graphics
 - Multipoint
 - ASCII file




Profile, Source Alignment



- With *Source* set to **Alignment**, the selected alignment is profiled when the LL corner of the profile window is located


Profile, Source Graphics



- When the *Source* is set to **Graphic**, the user is first prompted to identify a 'graphic' in the design file and then the LL Profile corner


Profile, Source Multi-Point

- With the *Source* set to **Multipoint**, the user can pick any points they wish in the CAD file view.
- Reset when done choosing points
- Identify the LL of the Profile window with a data point




Profile – Include Leaf

- Include relates to the Features that will be displayed.
 - Crossings
 - Projected
 - Bandwidth
 - Planimetrics
 - Show Data Outside




Profiling - Offsets Leaf

- Typically the ground line is shown in the profile window at the centerline
- The **Offsets** tab allow additional surface lines to be shown *offset* from the Profile baseline



Profiling - Offsets



- Each ground line is given a different Symbology and is wrapped into the Advanced Tab of the Surface Properties


Profiling - Controls

Define:

Any *Limits*

- Elevation
- Station


Window *Clearance*



Elevation Limits

- *Elevation Limits* (vertical right / left axis range of elev.) can be manually set by the user

- Just be aware that it can be set too small and may not show the complete surface info




Profile Display (Symbology)

● Symbology:


- ♣ Axes
- ♣ Grid
- ♣ Details

● Axes tab:

- ♣ Left Axis
- ♣ Bottom Axis
- ♣ Right Axis
- ♣ & Other Axes




Profile ID Node



● An InRoads Profile:


- ♣ Is typically placed in 'Pencil'
- ♣ Has an ID node at the lower left corner to identify it
- ♣ Is stored graphically in CAD only, not an InRoads file
- ♣ Should be moved as a 'whole', not in pieces
- ♣ Can simply be deleted if not wanted

Surface Data Updating



- Once the Profile is displayed the *Surface Data* can be updated within the profile window


Profile Updating



- The *Grid*, *Axis*, and *Title* information cannot be updated, only the *Surface Data* and the Features inside it
- Go to **InRoads > Evaluation > Profile > Update Profile**


Update Profile

- Choose the *Profile Set*
- Mode:
 - Refresh
 - Display On
 - Display Off
- Surface
- Offsets
- Crossings...
- Projected...




Batch File - Open & Save

- *InRoads > File > Save As* brings up the 'Save As' dialog box.
- Set the Save as Type to **Projects (*.rwk)**
- Pick the **Options...** button in the corner




The Project File (.rwk)

- The individual components of the project must be appropriately set on each tab
- This dialog creates an ASCII file that has the locations of the individual files listed



The RWK Text File



- This ASCII file can be viewed and further edited in a simple text editor like Notepad

Profile - Summary

- The Profile, using a *Source control* (align, graphic, data point), displays DTM data along that control
- Profiles can have *multiple Surfaces* and Offsets
- Surface Properties drive the *DTM profile symbology*
- *Each Axis* has settings for the *Tick, Title, and Label*
- Any profile *display configurations* can be saved and later recalled from the *civil.xin* file
- Display the Profile with the *Pencil Lock 'on'*
- A *Profile ID node* is placed in the LL of the Profile
- An *'rwk' file* can Load & Save data in Batch